

Instruction Manual

Hug-a-Hippo™



INTRODUCTION

Thank you for purchasing the **Hug-a-Hippo**™!

The happy hippo keeps little ones company on all their adventures. Give it a squeeze to enjoy phrases, music and satisfying textures.



INCLUDED IN THE PACKAGE

- Hug-a-Hippo™
- Quick Start Guide

WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please save this Instruction Manual as it contains important information.

ATTENTION

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes, cordons et vis d'emballage. Ils ne font pas partie du jouet.

NOTE

Il est conseillé de sauvegarder ce manuel d'utilisation car il comporte des informations importantes.

WARNING

Keep this soft toy out of the sleeping environment for babies under twelve months to avoid suffocation risk.

ATTENTION

Garder cette peluche hors de l'environnement de sommeil des bébés de moins de douze mois afin d'éviter tout risque de suffocation.étiquettes, cordons et vis d'emballage. Ils ne font pas partie du jouet.

GETTING STARTED

Battery Removal and Installation

- 1. Make sure the unit is turned Off.
- Find the battery cover located inside the back of the unit, use a screwdriver to loosen the screw and then open the battery cover.
- 3. Remove old batteries by pulling up on one end of each battery.
- Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (The use of new, alkaline batteries is recommended for maximum performance.)
- 5. Replace the battery cover and tighten the screw to secure.



IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- · Do not short-circuit the supply terminals.
- · Remove batteries during long periods of non-use.
- · Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEARI E BATTERIES

- Remove rechargeable batteries (if removable) from toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

\triangle

WARNING:

Adult assembly required for battery installation. Keep batteries out of reach of children.



ATTENTION:

Les piles ou accumulateurs doivent être installés par un adulte.

Tenir les piles ou accumulateurs hors de portée des enfants.

PRODUCT FEATURES

1. On/Off/Volume Switch

To turn the unit On, slide the On/Off/ Volume Switch to the Low volume I) or High volume I) position. You will hear an opening tune, fun sounds, a phrase and a song. To turn the unit Off, slide the On/Off/Volume Switch to the Off ● position.



2. Automatic Shut-Off

To preserve battery life, the **Hug-a-Hippo**™ will automatically power down after approximately 20 seconds without input. The unit can be turned on again by pressing the **Light-Up Heart Button**.

NOTE

If the unit powers down, please install a new set of batteries.

ACTIVITIES

1. Light-Up Heart Button

Press the **Light-Up Heart Button** to hear cute sounds, playful melodies, sing-along songs and fun phrases. The light will change colors with the sound.



MELODIES

- Dill Pickles Rag
- 2. MacNamara's Band
- 3. The Entertainer
- 4. Colonel Bogey March
- 5. Humpty Dumpty
- 6. On Top of Old Smokey
- 7. Oats, Peas, Beans, and Barley Grow
- 8. Pat-a-Cake
- 9. Skip to My Lou
- 10. Blue Danube Waltz
- 11 Aiken Drum
- 12. Daring Young Man on the Flying Trapeze
- 13. Toyland
- 14. Looby Loo
- 15. Mulberry Bush

SONG LYRICS

Song 1

I'm a happy hippo,
I love to play with you!
I'm a happy hippo,
There's lots for us to do!

Song 2

Oh, we can play together, We can play together, We can play together, Just you and me!

Song 3

Let's go on adventures together. We can explore and we can play. We are best friends.

CARE & MAINTENANCE

- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- Keep the unit out of direct sunlight and away from any direct heat sources.
- Remove the batteries if the unit will not be in use for an extended period of time.
- Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.
- The hippo is machine washable. Please remove the Electronic Module before cleaning and follow the washing instructions on the tag.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

- 1. Turn the unit Off.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit stand for a few minutes, then replace the batteries.
- 4. Turn the unit **On**. The unit should now be ready to use again.
- 5. If the unit still does not work, install a new set of batteries.

IMPORTANT NOTE

If the problem persists, please contact our Consumer Services Department at 1-800-521-2010 in the U.S., 1-877-352-8697 in Canada, or by going to our website vtechkids.com and filling out our Contact Us form located under the Customer Support link. Creating and developing VTech products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions you might have. A service representative will be happy to help you.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Supplier's Declaration of Conformity

47 CFR § 2.1077 Compliance Information

Trade Name: VTech®

Model: 5777

Product Name: Hug-a-Hippo™

Responsible Party: VTech Electronics North America, L.L.C.

Address: 1156 W. Shure Drive, Suite 200

Arlington Heights, IL 60004

Website: vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

Visit our website for more information about our products, downloads, resources and more.

vtechkids.com vtechkids.ca

Read our complete warranty policy online at vtechkids.com/warranty vtechkids.ca/warranty

