

Instruction Manual


Snuggles the Octopus™



INTRODUCTION

Thank you for purchasing **Snuggles the Octopus™**.

There's an ocean of textures and sounds to explore. Eight arms excite little ones with colorful fabrics, music and more!



INCLUDED IN THE PACKAGE

- Snuggles the Octopus™
- · Quick Start Guide

WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please save this Instruction Manual as it contains important information.

ATTENTION

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes, cordons et vis d'emballage. Ils ne font pas partie du jouet.

NOTE

Il est conseillé de sauvegarder ce manuel d'utilisation car il comporte des informations importantes.

WARNING

Keep this soft toy out of the sleeping environment for babies under twelve months to avoid suffocation risk.


ATTENTION

Garder cette peluche hors de l'environnement de sommeil des bébés de moins de douze mois afin d'éviter tout risque de suffocation.

GETTING STARTED

Battery Removal and Installation

- 1. Make sure the unit is turned Off.
- Find the battery cover located on the back of the unit, use a screwdriver to loosen the screw and then open the battery cover.
- 3. Remove old batteries by pulling up on one end of each battery.
- Install 2 new AAA (AM-4/LR03) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended.)
- Replace the battery cover and tighten the screw to secure.



Λ

WARNING:

Adult assembly required for battery installation. Keep batteries out of reach of children.

Λ

ATTENTION:

Les piles ou accumulateurs doivent être installés par un adulte. Tenir les piles ou accumulateurs hors de portée des enfants.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- · Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.

- · Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES

- Remove rechargeable batteries (if removable) from toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- · Do not charge non-rechargeable batteries.

PRODUCT FEATURES

1. On/Off/Volume Switch

To turn the unit **On**, slide the **On/Off/ Volume Switch** to the Low volume

or High vol



2. Automatic Shut-Off

To preserve battery life, **Snuggles the Octopus™** will automatically power down after approximately 20 seconds without input. The unit can be turned on again by pressing any button.

NOTE

If the unit powers down or if the light fades out during play, please install a new set of batteries.

ACTIVITIES

1. Octopus Button

Press the **Octopus Button** to hear phrases about the octopus. The **Light-Up Starfish** will flash with the sound.



2. Musical Heart Button

Press the **Musical Heart Button** to hear songs and melodies. The **Light-Up Starfish** will flash with the sound.



3. Coral Button

Press the **Coral Button** to hear a variety of ocean and water sounds. The **Light-Up Starfish** will flash with the sound



MELODIES

- 1. Sailing, Sailing
- 2. Sailor's Hornpipe
- 3. I'm Forever Blowing Bubbles
- 4. Go Round and Round the Village
- 5. Twinkle, Twinkle Little Star
- 6. While Strolling Through the Park One Day
- 7. Boys and Girls Go Out to Play
- 8. Chopsticks
- 9. Toyland
- 10. Row, Row, Row Your Boat

- 11. Ten in the Bed
- 12. Six Little Snails
- 13. Oh, Dear! What Can the Matter Be?
- 14. Pussy Cat, Pussy Cat
- 15. Good Morning, Merry Sunshine

SONG LYRICS

Song 1

Red, orange, blue, yellow, Pink, green and purple legs. A rainbow of legs swimming in the sea, Wiggling all around me.

Song 2

I swim around the ocean, the ocean so blue. I wiggle and giggle and take in the view.

Song 3

I stretch out my arms to give you a hug, snuggle in close and cuddle up my friend.

CARE & MAINTENANCE

- 1. Keep the unit clean by wiping it with a slightly damp cloth.
- Keep the unit out of direct sunlight and away from any direct heat sources.
- Remove the batteries if the unit will not be in use for an extended period of time.
- Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.
- 5. The octopus is surface washable only.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

- 1. Turn the unit Off.
- 2. Interrupt the power supply by removing the batteries.
- 3. Let the unit stand for a few minutes, then replace the batteries.
- 4. Turn the unit \mathbf{On} . The unit should now be ready to use again.
- 5. If the unit still does not work, install a new set of batteries.

IMPORTANT NOTE

If the problem persists, please contact our **Consumer Services Department** at **1-800-521-2010** in the U.S. or **1-877-352-8697** in Canada, or by going to our website at **vtechkids.com** and filling out our **Contact Us** form located under the **Customer Support** link. Creating and developing VTech products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions that you might have. A service representative will be happy to help you.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- · Consult the dealer or an experienced radio/TV technician for help.

CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Supplier's Declaration of Conformity

47 CFR § 2.1077 Compliance Information

Trade Name: VTech® 5779

Product Name: Snuggles the Octopus™

Responsible Party: VTech Electronics North America, L.L.C.

Address: 1156 W. Shure Drive. Suite 200

Arlington Heights, IL 60004

Website: vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

CAN ICES-003(B)/NMB-003(B)

Visit our website for more information about our products, downloads, resources and more.

vtechkids.com vtechkids.ca

Read our complete warranty policy online at vtechkids.com/warranty vtechkids.ca/warrantv

